



VISIONLINK®

CONFIGURE ASSET VISIBILITY RULE —


GETTING STARTED IN VISIONLINK®

The VisionLink® Fluid Analysis space is expanding in 2025. To ensure a smooth transition to VisionLink Fluid Analysis powered by S•O•SSM Services, **start preparing today!**


Please note, VisionLink supports the ability to restrict asset visibility to a subset of customer users within your organization.

HOW THE ASSET VISIBILITY RULE WORKS:


Customer users with VisionLink Administrator access can modify asset visibility rules for individuals with Standard or Read Only access by navigating to Manage > Users.



+ Click the "Invite" button, add the user information, and select the pencil icon in the Asset Visibility column.



+ Navigate to Manage > Users page.



+ Select the required Asset Inclusion option and configure the asset visibility settings.

For more information on Asset Visibility, see the VisionLink Help Center for guided tours and FAQs:

- + Configure Asset Visibility Settings Tour
- + [FAQs > What is Asset Visibility?](#)

